

Drain Bag Instructions

Needed:

1 x 15" x 12"

1 x 52" ribbon for the strap

1 label

Press a double fold from the top ($\frac{1}{2}$ " fold, then a 1" fold)

Open the folds

Fold the fabric in half (short sides together)

Stitch down the side and across the bottom with either an overlocker or straight stitch and zigzag the raw edge.



Fold over the top folds. Tuck the ribbon ends under the fold either side (seam & opposite on the fold). Fold the ribbons up over the hem. Tuck a folded label under the hem.

Top stitch $\frac{1}{4}$ " from the bottom fold & $\frac{1}{4}$ " from the top folds.



Turn through & push out the corners.

Finished!



WWW.CFORC.CO.UK